

WALL MOUNTED/PEDESTAL MOUNTED STAINLESS STEEL 304 EYE/FACE WASH

ECONOMY RANGE

Item Code	Description
H-D5020	OPEN BOWL WALL MOUNTED 304 STAINLESS STEEL EYE/FACE WASH WITH POLY SIGN

The Economy Range of Eye/Face Wash in 304 stainless-steel is wall-mounted with an open bowl. This eye/face wash with twin spray nozzles safeguarded by dust covers. Activated effortlessly via the push plate, these covers lift off to reveal the powerful yet gentle spray. With an inbuilt flow regulator valve ensuring optimal safety to the eyes, water flow, you can trust in its reliability during emergencies. The eye wash diffusers, equipped with fine mesh strainers, deliver a gentle aerated flow of water at 12 Liters per minute, meeting ANSI 358.1-2014 standard. While primarily intended for indoor use, this unit is versatile enough for outdoor placement in areas free from overheating risks.

SPECIFICATIONS	
OPERATING PRESSURE	2.0 to 6 BAR G (29 to 87 PSI)
MINIMUM FLOW AT OPERATING PRESSURE	Shower: 76 litres/minute minimum (20 US Gallons). Eye/face wash: 12 litres/minute minimum (3 US Gallons)
MINIMUM AMBIENT OPERATING TEMPERATURE	5° C (41° F)
MAXIMUM AMBIENT OPERATING TEMPERATURE	35° C (95° F)

PEDESTAL MOUNTING OPTIONS AVAILABLE	
Item Code	Description
H-D5020CP	OPEN BOWL WALL MOUNTED 304 STAINLESS STEEL EYE/FACE WASH COMPLETE WITH PP SIGN AND SS 304 PEDESTAL
H-D5020CPG	OPEN BOWL WALL MOUNTED 304 STAINLESS STEEL EYE/FACE WASH COMPLETE WITH PP SIGN AND GRP PEDESTAL
H-DA003	GRP RED FOOT CONTROL PANEL ASSEMBLY FOR EYE/FACE WASH ACTIVATION SUITS H-D5016, H-D5017 & H-D5020

