



TECHNICAL DATA SHEET

COMBINATION DRENCH SHOWER AND EYE /FACE WASH WITH SS DUST COVER

MODEL CS 9309

Free-standing emergency drench shower operated by a full flow stay open ball valve with rigid pull rod.

Made from galvanised pipe coated in Maestro emergency green, with heavy cast floor flange for rigid support.

Eye wash has a stainless steel receptor with twin chrome plated brass eye wash heads with automatic pressure and volume control and stainless steel dust cover operated by a push-flap with stay open ball valve without a basin.

All Maestro eye wash units are fitted with Maestro's unique Flo-Jo® self-draining device which reduces the risk of freezing and build up of bacteria.

Dust caps are fitted to eye/face wash heads as standard.

All units are supplied with a self-adhesive safety sign.

Recommended flow pressure to be available on supply line at all times to be 35-60 psi (2.5-4 bar).

INSTALLATION:

Prior to installing equipment ensure mains water supply pipe is thoroughly flushed.

PACKAGING:

Dimensions: 1110 x 380 x 375mm

Weight: 21.5 kgs.

